



## REPACKING THE RAILS ON A MONORAIL WATERROWER

### STEP 1

Starting with the top of the box, tape along the middle seam, then along the side seams. Once finished, turn the box up-side down.



### STEP 2

First pack the rails by inserting into the sides of the insert and securing the flap over the rail with packaging tape. Repeat on other side.



### STEP 3

With the box insert laying with the dolly wheels facing the rear, guide the rear foot end of the rail into the box insert. Be sure the bungee comes through the opening on the back end of the box insert as shown below.



### STEP 4

Before placing the rail assembly into the box, be sure to attach the bungee to the side of the box insert.



## STEP 5

See the image to the right for reference on how the rail assembly should look before going into the box.

SEAT SECURED ON THE OUTSIDE OF THE OPPOSITE END  
RAILS SECURED AND TAPED ON THE SIDES  
REAR LEG PLACED INTO THE INSERT NEAR THE DOLLY WHEELS



## STEP 6

Grab the rail assembly on the area under the seat and place the rail assembly into the box as shown. If needed, gently pull the reinforced corner of the box to make room as you are lowering the rail assembly into the box.



## STEP 7

Once the rail assembly is in the box, place the two cardboard inserts on the top of the rail assembly to keep it from shifting during transport. Once the rail is secure, finish taping the box along the seams.

