



REPACKING THE TANK ASSEMBLY ON A MONORAIL WATERROWER

STEP 1

Starting with the top of the box right side up, tape along the center, then along the side seams. Once finished, turn the box up-side down.



STEP 2

Pack the tank assembly. Secure the recoil belt by looping it around the forward riser bracket. Secure the handle by looping an elastic band around one side, thread under the top deck, then back over the other side.



STEP 3

To prevent remaining water drops from leaking, place a plastic bag between the rubber grommet and the tank stopper.



STEP 4

Slide the cardboard insert over the bottom deck. Flip the tank assembly over and place it in the box.





STEP 5

Pack the footboard by inserting the footboard into the footboard packaging. Lay footboard on top of the tank in the box. Pack up the hardware, small parts and the syphon pump and lay them in the box.



STEP 7

Once the tank assembly, footboard, and smaller parts are packaged up, Securely tape all of the seams on the box.

